

Contents

1	Introduction	1
	References.	6
2	Design Influence Area	7
2.1	Heat Treatment Specifications in Drawings.	9
2.1.1	Specifications for Annealing Processes	9
2.1.2	Specifications for Hardening and Tempering.	11
2.1.3	Specifications for Surface Hardening	13
2.1.4	Specifications for Case Hardening.	14
2.1.5	Specifications for Nitriding and Nitrocarburizing	21
2.1.6	Specifications for Boriding	24
2.2	Thermal Stresses and Notch Effects	25
2.3	Damage Examples—Construction.	27
	References.	43
3	Material Purchasing Influence Area	47
3.1	Case-hardening Steels	48
3.2	Quenched and Tempered Steels	59
3.3	Nitriding Steels	66
3.4	Martensitic Stainless Steels	69
3.5	Precipitation Hardening Steels.	71
3.6	Tool Steels	72
3.7	Damage Examples—Material Purchase	74
	References.	85
4	Material Influence Area	87
4.1	Trace Elements.	88
4.2	Segregation.	89
4.3	Non-metallic Inclusions.	90
4.4	Hardenability	91

4.5	Damage Examples—Material	91
	References.	122
5	Manufacturing Influence Area Before Heat Treatment.	125
5.1	Uneven Material Removal	125
5.2	Residual Stresses	126
5.3	Surface Hardening	129
5.4	Non-removed Functional Layers	130
5.5	Passive Layers	132
5.6	Damage Examples—Manufacturing Before Heat Treatment	133
	References.	150
6	Heat Treatment Influence Area	153
6.1	Process Parameters.	155
6.1.1	The Heating Phase	156
6.1.2	The Holding Phase.	175
6.1.3	The Quenching Phase.	195
6.1.4	Furnace Atmospheres.	222
6.2	Thermochemical Heat Treatments	230
6.2.1	Damage Examples—Case Hardening	231
6.2.2	Damage Examples—Nitriding/Nitrocarburizing	245
	References.	250
7	Manufacturing Influence Area After Heat Treatment.	253
7.1	Damage Examples—Manufacturing After Heat Treatment.	255
	References.	274
8	Operating Conditions Influence Area	277
8.1	Damage Examples—Operating Conditions	282
	References.	312